

UC-CC864/DE-CE910/UE910-V2/HE920/HE910-V2 Windows 2000, Xp, Vista, 7 and 8 Driver

1w0300980 Rev.6 – 2014-03-06



APPLICABILITY TABLE

| PRODUCT |
|-----------------|
| UC864 Family |
| CC864 Family |
| DE910 Family |
| CE910-DUAL |
| HE920 |
| UE910-V2 Family |
| HE910-V2 Family |

| SW Version |
|---------------|
| U8.00.05 |



License Agreements

License Agreements

The software described in this document is the property of Telit and its licensors. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement.

Copyrighted Materials

Software and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the software or documentation may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without prior written permission of Telit

High Risk Materials

Components, units, or third-party products used in the product described herein are NOT fault-tolerant and are NOT designed, manufactured, or intended for use as on-line control equipment in the following hazardous environments requiring fail-safe controls: the operation of Nuclear Facilities, Aircraft Navigation or Aircraft Communication Systems, Air Traffic Control, Life Support, or Weapons Systems (High Risk Activities"). Telit and its supplier(s) specifically disclaim any expressed or implied warranty of fitness for such High Risk Activities.

Trademarks

TELIT and the Stylized T Logo are registered in Trademark Office. All other product or service names are the property of their respective owners.

Copyright © Telit Communications S.p.A. 2014.



1. Introduction

1.1. Scope

This document should provide information needed to install the USB drivers for Telit modules.

1.2. Audience

This User Guide is intended for users who need to install and use UC864, CC864, DE910, CE910, UE910-V2, HE920 or HE910-V2 Telit modem.

1.3. Contact Information, Support

For general contact, technical support, to report documentation errors and to order manuals, contact Telit Technical Support Center (TTSC) at:

TS-EMEA@telit.com
TS-NORTHAMERICA@telit.com
TS-LATINAMERICA@telit.com
TS-APAC@telit.com

Alternatively, use:

<http://www.telit.com/en/products/technical-support-center/contact.php>

For detailed information about where you can buy the Telit modules or for recommendations on accessories and components visit:

<http://www.telit.com>

To register for product news and announcements or for product questions contact Telit Technical Support Center (TTSC).

Our aim is to make this guide as helpful as possible. Keep us informed of your comments and suggestions for improvements.

Telit appreciates feedback from the users of our information.

1.4. Product Overview

UC864 modules contain a fully featured HSDPA modem and UMTS/GSM/GPRS module, compatible with the other Telit GSM/GPRS modules.





Caution or Warning – Alerts the user to important points about integrating the module, if these points are not followed, the module and end user equipment may fail or malfunction.



Tip or Information – Provides advice and suggestions that may be useful when integrating the module.

All dates are in ISO 8601 format, i.e. YYYY-MM-DD.

This section lists the paragraph and font styles used for the various types of information presented in this user guide.

| Format | Content |
|------------------|---|
| Arial monospaced | Filesystem paths, and Windows Xp, Vista and 7 OS menu items |



3. USB driver download and installation


3.1. Installation

The following list of files needs to be available on the PC used for the installation procedure:

- TelitUSBInstaller_Qc_xx.xx.xx.zip (xx.xx.xx depends on the version)

To install the USB driver follow these steps:


1. Download driver archive and uncompress it in a specific directory (e.g. c:\Telit_Usb_driver) where the installer executable can be found
2. **If connected, disconnect the module from the PC. If installed, uninstall previous versions of the driver using following steps:**
 - a. **Start → ControlPanel;**
 - b. **Double click on “Add or Remove Programs”;**
 - c. **Scroll down until “Windows Driver Package – Telit (Telit_XXX)... ”**



- d. **Firstly, select “Windows Driver Package – Telit Wireless Solutions (telitusbser) Modem” and press on “Change/Remove” button.**


- e. **The following window will appear, press Yes:**






f. Now remove the Ports driver.

3. Run the installer and follow the instructions



If there appears one of the following windows click “Continue anyway” or “Install this driver software anyway”





4. After finishing the installation connect the module to the PC using the USB cable: the procedure “*Found new hardware wizard*” will start. If requested, don't let Windows connect to Windows Update and choose “*Install the software automatically (Recommended)*”.




4. Dial-Up Connection

4.1. Creation of dialup connection on Telit USB Modem Port

To create a Dial-Up connection:


1. Click on Start -> Control Panel. Then click on “Network and Internet connections” as shown in the following picture.



UC-CC864/DE-CE910/UE910-V2/HE920/HE910-V2 Windows 2000, Xp, Vista, 7 and 8 Driver

1v0300980 Rev.6 – 2014-03-06


2. Click on “Create a connection to the network at your workspace”



3. Tick “Dial-up connection” checkbox, then click “Next”.



6. Type the phone number (“*99#” for UMTS modules or “#777” for CDMA modules) then click “Next”.



7. Tick “Do not use my smart card” radio button then click “Next”



UC-CC864/DE-CE910/UE910-V2/HE920/HE910-V2 Windows 2000, Xp, Vista, 7 and 8 Driver

1vv0300980 Rev.6 – 2014-03-06

8. Check "Add a shortcut..." checkbox then Click "Finish" to complete the procedure.



UC-CC864/DE-CE910/UE910-V2/HE920/HE910-V2 Windows 2000, Xp, Vista, 7 and 8 Driver
 1vv0300980 Rev.6 – 2014-03-06



The windows below should appear, and after them the connection is active.



Browse the Internet to check that connection is available.



