

HE Windows CE 5 User Guide

1VV0300928 rev. 1 – 2011-11-03



Applicable Products

Product
HE863-EUx
HE910



Contents

- 1. Introduction 5**
 - 1.1. Scope5**
 - 1.2. Audience5**
 - 1.3. Contact Information, Support.....5**
 - 1.4. Product Overview6**
 - 1.5. Document Organization6**
 - 1.6. Text Conventions6**
 - 1.7. Document history.....6**
- 2. System setup 8**
 - 2.1. General Overview9**
 - 2.2. Pre-requirements11**
 - 2.3. Adding HE TELIT MODULE support in the OS image - Using the binary14**
- 3. Using the HE TELIT MODULE..... 17**
 - 3.1. The serial API17**
 - 3.1.1. CreateFile17
 - 3.1.2. WriteFile.....19
 - 3.1.3. ReadFile.....21
 - 3.1.4. CloseHandle22
 - 3.2. PPP Connection24**



1.4. Product Overview

HE modules contain a fully featured HSDPA modem and UMTS/GSM/GPRS module, compatible with the other Telit GSM/GPRS modules.

1.5. Document Organization

This manual contains the following chapters:

- “Chapter 1, Introduction” provides a scope for this manual, target audience, technical contact information, and text conventions.
- “Chapter 2, System setup” describes how to add the Telit HE USB driver in a Windows CE 5.0 image.
- “Chapter 3, Device Driver” describes how to use the Telit HE USB driver for interacting with the chosen modem.

1.6. Text Conventions

This section lists the paragraph and font styles used for the various types of information presented in this user guide.



Danger – This information MUST be followed or catastrophic equipment failure or bodily injury may occur.



Caution or Warning – Alerts the user to important points about integrating the module, if these points are not followed, the module and end user equipment may fail or malfunction.



Tip or Information – Provides advice and suggestions that may be useful when integrating the module.

Format	Content
Arial monospaced	Windows CE shell commands at command prompt, filesystem paths, source code examples and menu items

All dates are in ISO 8601 format, i.e. YYYY-MM-DD.


1.7. Document history

Revision	Date	Changes
ISSUE #0	2011-05-03	First Release



2.1. General Overview

In the following image it is shown a diagram of USB software/hardware interaction in a Windows CE system with a HE module attached:



From the bottom of the stack:

- TELIT MODULE: Telit modem connected through an USB port.
- USB: serial bus for interfacing devices to a host computer.
- USB Host Controller: a combination of hardware and software that is responsible for the following actions:
 - Detecting the insertion and removal of USB devices
 - Managing flow control between the host and USB devices
 - Managing data flow between the host and USB devices




2.2. Pre-requirements

For correctly building a Windows CE 5.0 image with the TELIT MODULE USB driver on a headless system the following pre-requirements need to be satisfied:

- Microsoft Platform Builder for CE 5.0.
- An OS design with the USB host controller supported.
- Knowledge of Windows CE OS image and subproject creation.


Please note that there are different ways for enabling the USB host controller and they depend on the considered hardware. In our test platform the USB host controller can be enabled during the initial image creation wizard (in the Core OS Services step), as the following image suggests:





- Open the file *project.reg* and, at its end, paste the content of the file *CDCACMDriver_HEXXX.reg* where XXX is the module that you are going to use.





- Recreate the OS image.

Now you should have the TELIT MODULE driver integrated into your OS image. Start your system with the just created OS image and, after the boot, plug the device into your target: if the connection succeeds you should see the three virtual serial ports described in paragraph 2.1 ready to be used.



3. Using the HE TELIT MODULE

In this chapter it is explained how to programmatically use the TELIT MODULE (via the serial port API) and how to setup a PPP connection.

3.1. The serial API

Application can interact with the TELIT MODULE through the virtual serial ports created by the driver (for example COM6). Windows CE 5.0 has a complete API for dealing with serial ports; following you can find all the most important calls with code examples. Further information can be found in Microsoft Developer Network.

3.1.1. CreateFile

This function creates, opens, or truncates a file, COM port, device, service, or console. It returns a handle to access the object.

Header:

winbase.h

Library:

coredll.lib

Syntax:

```
HANDLE CreateFile(
    LPCTSTR lpFileName,
    DWORD dwDesiredAccess,
    DWORD dwShareMode,
    LPSECURITY_ATTRIBUTES lpSecurityAttributes,
    DWORD dwCreationDisposition,
    DWORD dwFlagsAndAttributes,
    HANDLE hTemplateFile
);
```



Parameters:

lpFileName

[in] Pointer to a null-terminated string that specifies the name of the object, such as file, COM port, disk device, or console, to create or open.

dwDesiredAccess

[in] Type of access to the object. An application can obtain read-only access, write-only access, read/write access, or device-query access.

dwShareMode

[in] Share mode for the object. If this parameter is set to zero, the object cannot be shared. Subsequent open operations on the object fail until the handle is closed.

This parameter can be set to one or more values.

lpSecurityAttributes

[in] Not used.

dwCreationDisposition

[in] Action to take on files that exist, and which action to take when files do not exist.

dwFlagsAndAttributes

[in] File attributes and flags for the file.

hTemplateFile

[in] Ignored; as a result, this function does not copy the extended attributes to the new file.

Return Value:

An open handle to the specified file indicates success. If the specified file exists before the function call and *dwCreationDisposition* is set to *CREATE_ALWAYS* or



OPEN_ALWAYS, a call to GetLastError returns ERROR_ALREADY_EXISTS, even though the function has succeeded. If the file does not exist before the call, GetLastError returns zero. INVALID_HANDLE_VALUE indicates failure. To get extended error information, call GetLastError.

Example:

```
HANDLE hModem;
hModem = CreateFile( TEXT("COM6:"),
                    GENERIC_READ | GENERIC_WRITE,
                    0,
                    NULL,
                    OPEN_EXISTING,
                    0,
                    NULL);
if (hModem == INVALID_HANDLE_VALUE)
    // error opening port; abort
```

Further information on the parameters' values can be found at <http://msdn.microsoft.com/en-us/library/aa914735.aspx>.

3.1.2. WriteFile

This function writes data to a file. WriteFile starts writing data to the file at the position indicated by the file pointer.

Header:

winbase.h

Library:

coredll.lib

Syntax:

```
BOOL WriteFile(
    HANDLE hFile,
    LPCVOID lpBuffer,
    DWORD nNumberOfBytesToWrite,
    LPDWORD lpNumberOfBytesWritten,
    LPOVERLAPPED lpOverlapped
);
```



(typically WINCE600), \PUBLIC\COMMON\OAK\DRIVERS\NETSAMP\RASDIAL compile it and add to the OS image. This program setups the PPP connection according to the selected RAS phonebook entry.

- Start your target and, after the boot, plug the HE. Upload the created RAS phonebook configuration file to the target (for example using the File Viewer tool that you can find in the menu *Target* → *Remote Tools* → *File Viewer*).
- Launch in the target the application *RASENTRY* with the path of the RAS phonebook configuration file as the first argument; you can run an application in your system by choosing the menu voice *Target* → *Run Programs* and selecting the desired application.
- Launch in the target the application *RASDIAL* with the name of the created RAS phonebook entry (Telit RAS in the above example) as the first argument.

If all is successful the PPP connection should be setup: you can launch the *ipconfig* application for checking the target ip address.

